

Apoorva S  
231047026

## CAM FREENAS IN WINDOWS

### Step 1: Downloads and Installation

Download and install VMware



### Step 2: Download freenas

Download previous version i.e

Freenas->stable->Release->x64-> FreeNAS-11.2-RELEASE

# TrueNAS CORE 13.0-U5.3

Current Stable Version, Recommended for Production use.


**Download** >

+ Release Notes and Checksums

+ Manual Update - Upgrade to the Latest Stable Version of CORE

[Download Previous Versions](#)

[Download Future Previews](#)

 **RELEASE**  
6 FILES  
SIZE: 1.42GB

 **x64**  
4 FILES  
SIZE: 984.97MB



**FreeNAS-11.2-RELEASE.debug.txz**

SIZE: 409.51MB  
LAST MODIFIED: WED. DECEMBER 5TH, 2018 - 09:26PM



**FreeNAS-11.2-RELEASE.debug.txz.sha256**

SIZE: 145B  
LAST MODIFIED: WED. DECEMBER 5TH, 2018 - 09:26PM



**FreeNAS-11.2-RELEASE.iso**

SIZE: 575.46MB  
LAST MODIFIED: WED. DECEMBER 5TH, 2018 - 09:30PM



**FreeNAS-11.2-RELEASE.iso.sha256**

SIZE: 139B  
LAST MODIFIED: WED. DECEMBER 5TH, 2018 - 09:30PM

Step 3:

Go to VMware and click on the create a new virtual machine

## Welcome to VMware Workstation 17 Player



### Create a New Virtual Machine

Create a new virtual machine, which will then be added to the top of your library.



### Open a Virtual Machine

Open an existing virtual machine, which will then be added to the top of your library.



### Upgrade to VMware Workstation Pro

Get advanced features such as snapshots, virtual network management, and more.



### Help

View online help.

Then select the Installer disc image file i.e. freenas file. After choosing click on next.

New Virtual Machine Wizard

**Welcome to the New Virtual Machine Wizard**  
A virtual machine is like a physical computer; it needs an operating system. How will you install the guest operating system?

Install from:

☐ Installer disc:  
DVD RW Drive (D:)

☒ Installer disc image file (iso):  
C:\Users\MSIS\Downloads\FreeNAS-11.2-RELEASE.iso Browse...  
FreeBSD version 10 and earlier 64-bit detected.

☐ I will install the operating system later.  
The virtual machine will be created with a blank hard disk.

Help < Back Next > Cancel

Give name and add location and the click on next.

New Virtual Machine Wizard

**Name the Virtual Machine**  
What name would you like to use for this virtual machine?

Virtual machine name:  
Freenas

Location:  
C:\Users\MSIS\Documents\Virtual Machines\Freenas Browse...

< Back Next > Cancel

Then give 20GB to memory.

New Virtual Machine Wizard

**Specify Disk Capacity**  
How large do you want this disk to be?

The virtual machine's hard disk is stored as one or more files on the host computer's physical disk. These file(s) start small and become larger as you add applications, files, and data to your virtual machine.

Maximum disk size (GB): 20.0

Recommended size for FreeBSD version 10 and earlier 64-bit: 20 GB


☐ Store virtual disk as a single file

☒ Split virtual disk into multiple files


Splitting the disk makes it easier to move the virtual machine to another computer but may reduce performance with very large disks.

Help < Back Next > Cancel


Then click on the customized hardware



Then add 4GB to memory



After this give finish then you will get the install and upgrade page




Click on the Install and Upgrade then click ok


For inside work click ctrl+g

For outside the vm click ctrl+alt


Give yes




Then press space in the keyboard for apply \* on the blank space thenk click ok




Then give the password(sois@123)-> ok




Then click on the Boot via BIOS




Then it will boot the you will get the ip address



Then again reboot the system for add extra 20gb memory. After the reboot shut down the system




For that go to edit vm setting




And select IDE then click on next






Add memory 20GB




Then click on the power on button

Then take the ip address of freenas and past it in the browser you will get the freenas page.

| 192.168.10.131/ui/sessions/signin



Click on the legacy web interface and you need to give username(root) and password(sois@123)->login




Then goto storages

Storages->volume->manage volume

Give volume name(volume1) and then click on available disk(it will work only when you add extra memory in the freenas after installation)

Then click on the add volume in the bottom



Go to shell


Add any file you want to add

```
Shell

[root@freenas ~]# cd /mnt/apoorvavol/
[root@freenas /mnt/apoorvavol]# touch aa.txt
[root@freenas /mnt/apoorvavol]# ls
aa.txt
[root@freenas /mnt/apoorvavol]#
```









Go to services

Service->WebDAV->give password(sois@123)





The image shows a 'WebDAV' configuration window. It has a 'Start on boot' checkbox at the top left. The main area contains several fields: 'Protocol' is set to 'HTTP'; 'HTTP Port' is '8080'; 'HTTP Authentication' is set to 'Digest Authentication'; 'Webdav Password' and 'Confirm WebDAV Password' are both masked with dots. There are 'OK' and 'Cancel' buttons at the bottom. Information icons are present next to the port, authentication, and password fields.

Activate the window SMB

S3	 Stopped		<input type="button" value="Start Now"/>	<input type="checkbox"/> Start on boot
S.M.A.R.T.	 Stopped		<input type="button" value="Start Now"/>	<input checked="" type="checkbox"/> Start on boot
SMB	 Running		<input type="button" value="Stop Now"/>	<input type="checkbox"/> Start on boot
SNMP	 Stopped		<input type="button" value="Start Now"/>	<input type="checkbox"/> Start on boot

In the top click on the add window(smb)share, give the name(webshare) and select path and give allow guest access.



Then go to browser and give ip address like <http://192.168.10.131:8080/webshare>

Then you will get the credentials for username (WebDAV) password(sois@123)


Output:



**For shared folder follow the same steps till sharing**


Then open edit policy in the windows

click on the computer configuration->admintation templates->network->lambda workstation->enable insecure guest logons(keep it enable)->ok



Then go to This PC

This PC->...->Add network location->next->choose a custom network location->next



🖥️ > This PC



## Add Network Location

### Welcome to the Add Network Location Wizard

This wizard helps you sign up for a service that offers online storage space. You can use this space to store, organize, and share your documents and pictures using only a web browser and Internet connection.

You can also use this wizard to create a shortcut to a website, an FTP site, or other network location.

Next

Cancel




## Add Network Location

### Where do you want to create this network location?



#### Choose a custom network location

Specify the address of a website, network location, or FTP site.



And then you will get your shared folder

